

## MAJOR COMPONENTS (Information you need to operate this motorcycle)

### SUSPENSION

Each shock absorber (1) has 5 adjustment positions for different load or riding conditions. Use the pin spanner (2) and extension bar (3) to adjust the rear shock.


Always adjust the shock absorber position in sequence (1-2-3-4-5 or 5-4-3-2-1).

Attempting to adjust directly from 1 to 5 or 5 to 1 may damage the shock absorber.

Position 1 is for a light load and smooth road conditions.

Position 2 is the standard position.

Positions 3 to 5 increase spring preload for a stiffer rear suspension and can be used when the motorcycle is more heavily loaded.



(1) Shock absorber  
(2) Pin spanner

(3) Extension bar