

# Tires

Always check air pressure when your tires are “cold.” If you check air pressure when your tires are “warm” — even if your ATV has only been ridden for a few miles — the readings will be higher. If you let air out of warm tires to match the recommended cold tire pressures, the tires will be underinflated. Be sure to check tire pressure at the riding site, since changes in altitude can affect air pressure.

The recommended “cold” tire pressures are:

|            |                      | FRONT   | REAR  |
|------------|----------------------|---|---|
| NO CARGO   | RECOMMENDED PRESSURE | 4.4 psi (30 kPa ,<br>0.30 kgf/cm <sup>2</sup> ) | 3.6 psi (25 kPa ,<br>0.25 kgf/cm <sup>2</sup> ) |
|            | MAXIMUM PRESSURE     | 5.0 psi (34 kPa ,<br>0.34 kgf/cm <sup>2</sup> ) | 4.0 psi (28 kPa ,<br>0.28 kgf/cm <sup>2</sup> ) |
|            | MINIMUM PRESSURE     | 3.8 psi (26 kPa ,<br>0.26 kgf/cm <sup>2</sup> ) | 3.2 psi (22 kPa ,<br>0.22 kgf/cm <sup>2</sup> ) |
| WITH CARGO | RECOMMENDED PRESSURE | 4.4 psi (30 kPa ,<br>0.30 kgf/cm <sup>2</sup> ) | 3.6 psi (25 kPa ,<br>0.25 kgf/cm <sup>2</sup> ) |