

Gradually increase the lever and/or pedal pressure as you feel the brakes slowing your speed. The pressure used depends on your speed and the condition of the terrain you're riding. Slick, slippery or muddy ground requires gentler braking.

Pulling one or both brake levers or depressing the brake pedal too hard may cause the front and/or rear wheels to skid or slide out of control. If this happens, release all pressure on the lever(s) and/or pedal immediately. Steer straight ahead to regain control. Then gently reapply the brakes.

Independent use of only the front or rear brakes reduces stopping performance. Extreme braking may cause the wheels to lock, reducing control of the Sportrax.

When possible, reduce speed or brake before entering a turn. Closing the throttle or braking in mid-turn may cause wheel slippage which will reduce control of your Sportrax.