

# Wheels & Tyres

This ATV is equipped with low pressure tubeless tyres. Although the tyres are designed specifically for off-road use, they are not immune to punctures. Always select your riding area with care.

The following pages give detailed information on how and when to check your air pressure, how to inspect your tyres for wear and damage, and our recommendations for tyre repair and replacement.

## Air Pressure

Refer to *Safety Precautions* on page 94.

Properly inflated tyres are most important for safety, and will provide the best combination of handling, tread life, and riding comfort. Generally, underinflated tyres wear unevenly, adversely affect handling, and are more likely to fail from being overheated. Overinflated tyres make your ATV ride harshly, are more prone to damage from surface hazards, and wear unevenly.

Make sure the valve stem caps are secure. If necessary, install new caps.

Always check air pressure when your tyres are "cold." If you check air pressure when your tyres are "warm" – even if your ATV has only been ridden for a few miles – the readings will be higher. If you let air out of warm tyres to match the recommended cold tyre pressures, the tyres will be underinflated. Be sure to check tyre pressure at the riding site, since changes in altitude can affect air pressure.

The recommended "cold" tyre pressures are:

	FRONT	REAR
RECOMMENDED PRESSURE	20.0 kPa (2.9 psi)	20.0 kPa (2.9 psi)

## 138 Servicing Your Honda