

Loading

The combined weight of the rider, passenger, luggage and additional accessories must not exceed 167 kg (366 lbs), the vehicle capacity load. Luggage weight alone should not exceed 9 kg (20 lbs).

1. **Keep luggage and accessory weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located farther from the motorcycle's center of gravity, handling is proportionally affected.**
2. **Adjust tire pressure (TIRES, page 7), front fork air pressure and rear shockabsorber air pressure (SUSPENSION, page 10) to suit load weight and riding conditions.**
3. **Luggage racks are for light weight items. Bulky items too far behind the rider can cause wind turbulence that impairs handling.**
4. **All cargo and accessories must be secure for stable handling. Re-check cargo security and accessory mounts frequently.**
5. **Do not attach large, heavy items to the handlebars, front forks, or fender. Unstable handling or slow steering response may result.**