


Compression Damping

You can adjust the compression damping by the COMP adjuster on the left side of the front fork to suit the load or the road surface. Turn clockwise to increase compression damping (hard), or turn counterclockwise to decrease compression damping (soft).

The standard position is 12 clicks from the full hard position. The position for race tracks is the 10 clicks from the full hard position.

► When adjusting, be careful not to damage the adjuster.



NOTICE

Do not turn the adjuster beyond its limits. Adjust both left and right forks to the same spring preload.