Front Fork Protector Removal

Refer to Safety Precautions on page 45.

LEFT FRONT (2) (3) (4) (4) (4) (1)

- (1) bolts(2) front brake cable
- (3) cable guide(4) front fork protector

Removal

- 1. Remove the two bolts (1) securing the front fork protector.
- 2. Remove the front brake cable (2) from the cable guide (3).
- 3. Remove the front fork protector.

Installation

- 1. Attach the fork protector on the front fork.
- 2. Install the securing bolts and tighten them.