

- \* A manually operated tire pump should be used rather than the high pressure systems found in service stations. This will minimize the possibility of tire damage from overinflation.

		Front	Rear
TIRE SIZE		AT 24×8-11★★	AT 24×10-11★★
TIRE BRAND		TRACKER ATT GOOD YEAR	TRACKER ATT GOOD YEAR
NO CARGO	RECOMMENDED PRESSURE	3.6 psi (25 kPa, 0.25 kg/cm <sup>2</sup> )	3.6 psi (25 kPa, 0.25 kg/cm <sup>2</sup> )
	MAX. PRESSURE	4.0 psi (28 kPa, 0.28 kg/cm <sup>2</sup> )	4.0 psi (28 kPa, 0.28 kg/cm <sup>2</sup> )
	MIN. PRESSURE	3.2 psi (22 kPa, 0.22 kg/cm <sup>2</sup> )	3.2 psi (22 kPa, 0.22 kg/cm <sup>2</sup> )
WITH CARGO	RECOMMENDED PRESSURE	3.6 psi (25 kPa, 0.25 kg/cm <sup>2</sup> )	3.6 psi (25 kPa, 0.25 kg/cm <sup>2</sup> )

Fig. 4-34

Tire specifications

## ▲ WARNING

### POTENTIAL HAZARD

Operating this ATV with improper tires, or with uneven tire pressure.

### WHAT CAN HAPPEN

Use of improper tires on this ATV, or operation of this ATV with improper or uneven tire pressure, may cause loss of control, increasing your risk of an accident.

### HOW TO AVOID THE HAZARD

Always use the size and type tires specified in this Owner's Manual for this vehicle.

Always maintain proper tire pressure as described in this Owner's Manual.