

4. Add air to the recommended pressure.
  5. Apply the front brake and push down on the handlebars several times. Release the brake and recheck front fork air pressure. Release air if necessary to obtain the recommended pressure.
- NOTE: Do not exceed recommended air pressure or the ride will be harsh and uncomfortable.**
6. Reinstall the front fork air valve caps.

- 
4. Ajouter de l'air jusqu'à la pression recommandée.
  5. Appuyer sur le frein avant et presser le guidon vers le bas à plusieurs reprises. Relâcher le frein et remesurer la pression d'air dans la fourche avant. Si nécessaire, évacuer de l'air afin d'atteindre la pression recommandée.
- NOTE: Ne pas dépasser faute de quoi la conduite sera rude et inconfortable.**
6. Remettre en place les capuchons de valves de fourche avant.