


Elapsed Time Meter


The elapsed time meter will show minutes and seconds up to 59 : 59, and hours and minutes up to 23 : 59.

To reset:

1. Press the MODE-TIME button. The mode indicator will display "TIME".



2. Press and hold the RESET-TIME button for more than 3 seconds. The display will indicate "00 : 00".



3. Lightly press the RESET-TIME button for less than 1 second. The elapsed time meter will start counting time the instant the button is pressed.



- You can start the elapsed time meter before you start off the line in the enduro.

Example : To start the meter before 2 minutes

- (1) Press and hold the RESET-TIME button for more than 3 seconds. The display will indicate "00 : 00".

