| Symptom | Cause/remedy |
|------------------------------------|--|
| Apple CarPlay cannot be available. | Connected iPhone may be unsupported model. Check the compatible model with Apple CarPlay. ▶ P. 101 |
| | Connected iPhone may be unsupported iOS version. Update the iPhone to the newer version. |
| | To use Apple CarPlay, a headset connection is necessary. Connect a paired headset. P. 86 |
| | When connecting your iPhone, if it is recognized as iPod, disconnect the USB cable once, enable the Apple CarPlay (P. 80), and then reconnect the USB cable again. |
| | When a mobile network communication is unstable due to surrounding conditions or signal strength conditions, Apple CarPlay functions may not be available. |
| | When the paired headset connection is broken due to headset battery depletion or communication failure, Apple CarPlay cannot be used until the connection is restored. |
| | The screen will not switch to Apple CarPlay automatically, other than when the ignition switch is turned to OFF with Apple CarPlay is activated. |
| | Apple CarPlay cannot be available with USB connection via USB2 terminal (option). Check the USB connection, and then reconnect the USB cable via USB1 if necessary. |
| | Some USB cables may be incompatible with Apple CarPlay. Use certified cable to connect the iPhone. |
| | You have not agreed to enable Apple CarPlay. Reconnect the iPhone and enable to use CarPlay on the disclaimer screen. ▶ P. 102 |
| | Apple CarPlay setting on your iPhone may be disabled. Disconnect iPhone and enable the Apple CarPlay setting on your iPhone. |